

CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Part No.: **CAF1805C**

Est. Installation Time: **less than 10 min.**

Chrysler 300 (2005-10), Dodge Charger (2006-10) Magnum (2005-08)

1. The cabin filter is located under the cowl cover on the passenger side
2. Open the hood
3. Remove the cowl cover pushing the two tabs toward the front of the car
4. Swing down the cabin air filter housing access door.
5. Pull the older filter out
6. Insert the new filter with the air flow arrows pointing toward the windshield
7. Close the access door
8. Clip back the cowl cover

