CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Part No.: **CAF1807P / CAF1807C** Est. Installation Time: **less than 15 min.**

Ford Mustang (2005-13) OEM No. 4R3Z-19N619-AA

Cabin air filter located under the cowl grill on the passenger side

1. Open hood.
2. Remove the 2 screws securing half of the cowl cover on the passenger side





3. Remove the plastic clips ➔
4. Unclip the passenger side half of the cowl grill.
5. Unlatch the filter-frame from the housing tab (you might need to use flat screwdriver)
6. Pull out the old filter with the plastic frame from the housing
7. Insert the new filter with air-flow arrows pointing up – toward the open end of the frame (to ensure the air flow arrow will be pointing to the rear-end of the vehicles once the filter and the frame are fitted back into the housing).
8. Insert the filter frame back into the housing – push down and toward the rear-end of the vehicle to latch it back into the housing.
9. Return the cowl grill and make sure the clips snaps back in
10. Clip back the plastic “rivets” and secure the grill with the two screws
11. Close the hood



