



CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Part No.: **CAF1904P**

Est. Installation Time: **less than 15 min.**

Cadillac - ATS (13-16), CT6 (16), CTS (14-16), XTS (14-15); Chevrolet – Camaro (16), Impala (14-15), Volt (16)

The cabin air filter is located behind the glove box.

1. Squeeze the sides of the glove box toward the middle and pull out having the glove box swing down.



2. Remove the screws from the glove box, three on the bottom and four on the top, and remove the glove box.



3. Remove the cover by prying the tab and pulling it off.
4. Replace cabin air filter
5. Reverse steps 3-1.



This is only a guide and may not be for exact model. See Owner's manual and/or local mechanic for exact instructions for the particular model.