



# CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Item No.: **CAF9957P**

Est. Installation Time: **less than 20 min.**

Caddillac Escalade (14), Chevrolet Avalanche, Silverado 1500, 2500, 3500, Suburban 1500, 2500, 3500, Tahoe (07-12), GMC Sierra 1500, 2500, 3500, Yukon, XL 1500, XL 2500, XL 3500 (07-12)

**The cabin air filter is located behind the glove box**

1. Locate and remove the screws holding the right side insulator panel.
2. Remove the bolt holding the cabin air filter cover
3. Replace the cabin air filter
4. Reverse steps 2-1.



This is only a guide and may not be for exact model. See Owner's manual and/or local mechanic for exact instructions for the particular model.