

Part # C1037

Primary .4 - 1.1 Secondary Cannot Read Physical Inspection

1. Check for corrosion on terminals
2. Check for cracks or carbon tracking

