

CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Part No.: **CAF1815M**

Est. Installation Time: **less than 15 min**

The Cabin air filter is located behind the glove compartment

- Open the glove box
- Remove the panel on the right edge of the dash
- Remove the panel below the glove box
- Remove the four Phillips-head screws along the top edge of the glove box assembly
- Remove the Phillips-head screw behind the glove box
- Remove the Phillips-head screw on the bottom-left corner of the assembly - this screw will also require the long screwdriver
- Remove the Phillips-head screw on the bottom-right corner of the assembly
- Pull the glove box assembly from the dash by starting at the top-right edge. This will expose the filter housing unit. Leave all the wiring connected to the assembly and set it on the floor
- Unlatch the filter housing door from the right side, and remove it
- Remove the old filter from assembly, taking note the air flow arrow indicator on the side of the old filter
- Insert the new filter into the assembly, making sure the air flow direction is correct according to the arrow indicator
- Replace the rest of the glove box assembly by reversing the removal procedure

This is only a guide and may not be for exact model. See Owner's manual and/or local mechanic for exact instructions for the particular model.